NW854 – Wii Sports Gun

INSTRUCTION MANUAL

Thank you for purchasing the Logic3 Wii Sports Gun. As with all Logic3 products the NW854 has been built to the highest manufacturing standards and testing throughout its development to ensure you get the best possible product. Please read through and familiarise yourself with this manual before you use the product.

- LightGun for Nintendo Wii using Remote Control and Nunchuk
- Compatible with Nintendo Wii shooting games
- Realistic trigger click-action noise
- Cable tidy for Wii Nunchuk cable

Setup

1. Insert your Wii Remote Control into the top of the Sports Gun
2. Place your Wii Nunchuk into the back handle of the Sports Gun
3. Connect your Wii Nunchuk cable into the bottom of the Wii Remote Control
4. A Cable Tidy is provided for the Wii Nunchuk cable.
5. All button and controls of the Wii Remote Control and Wii Nunchuk will still be accessible.

   When the Wii Remote Control is inserted into the Sports Gun pressing the trigger will activate the 'B' button of the Remote Control

Should you have any connection or setup problems with the **Logic3 NW854** please contact our Technical Support Hotline on +44 01923 471 000– National call rates apply or E-mail **support@logic3.com**